

WWDC Wireless Wall Damper Control and R80DWL Damper Installation

- Install an R80DWL Damper in the trunk line supplying airflow to the space. If needed, additional dampers can be installed to define the space.
- Connect the damper to a separate 24VAC, 40VA Transformer (plug in type ok) using 18 or 20 gage thermostat cable.
- If more than one damper is installed, connect the additional damper to either the first damper or to the transformer using 2-conductor, 18 or 20 gage thermostat cable. Up to 6 dampers can be powered by one transformer.
- Install the batteries in the WWDC then mount the WWDC to the wall using the hardware provided.
- The WWDC Wall Damper Control and the damper actuator default to Zone 1.
- Power the damper - That's it! You're ready to control airflow to the space.

